

# TABLE OF CONTENTS

<b>1</b>	<b>Revision history</b>	<b>5</b>	3.5.5	SPEEDBRAKE LEVER FAULT	62
<b>2</b>	<b>Introduction</b>	<b>7</b>	3.5.6	ELAC 1(2) FAULT	63
<b>3</b>	<b>Fault description</b>	<b>9</b>	3.5.7	SEC 1(2)(3) FAULT	65
<b>3.1</b>	<b>DSC-21 AIR CONDITIONING / PRESSURIZATION / VENTILATION &amp; DSC-35 OXYGEN</b>	<b>9</b>	3.5.8	THS ELECTRIC MOTOR 1(2)(3) FAULT	66
3.1.1	PACK 1(2) FAULT	9	3.5.9	STABILIZER JAM	68
3.1.2	PACK 1(2) OVHT	10	3.5.10	PITCH TRIM RUNAWAY UP(DOWN)	70
3.1.3	PRESS SYS 1(2)(1+2) FAULT	11	3.5.11	L(R) ELEV FAULT	72
3.1.4	SLOW(RAPID) DECOMPRESSION	12	3.5.12	FLAP SYS 1(2) FAULT	73
3.1.5	COCKPIT OXY LO PRESS	13	3.5.13	SLAT SYS 1(2) FAULT	75
<b>3.2</b>	<b>DSC-22 AUTO FLIGHT</b>	<b>14</b>	3.5.14	FLAPS(SLATS) LOCKED (WTB)	77
3.2.1	FCU 1(2) FAULT	14	3.5.15	FLAPS/SLATS INDICATION FAULT	78
3.2.2	AP 1(2) FAULT	16	3.5.16	FORCED F/CTL LAWS	79
3.2.3	FD 1(2) FAULT	17	3.5.17	UPRT IMPULSE GENERATOR	81
3.2.4	TCAS MODE FAULT	18	<b>3.6</b>	<b>DSC-28 FUEL</b>	<b>82</b>
3.2.5	A/THR FAULT	19	3.6.1	L(R)(CTR) TANK LEAK	82
3.2.6	AUTOLAND WARNING LIGHT	20	3.6.2	L(R)(CTR) TANK PUMP 1(2) LO PR	83
3.2.7	NO LAND MODE	21	<b>3.7</b>	<b>DSC-29 HYDRAULIC</b>	<b>85</b>
3.2.8	NO FLARE MODE	22	3.7.1	G(B)(Y) RSVR LO LVL	85
3.2.9	FAC 1(2) FAULT	23	3.7.2	G(B)(Y) RSVR LO LVL (FULL LEAK)	87
<b>3.3</b>	<b>DSC-24 ELECTRICAL</b>	<b>25</b>	3.7.3	G(B)(Y) RESERVOIR OVHT	89
3.3.1	GEN 1(2) FAULT	25	3.7.4	G(B)(Y) RESERVOIR LOW AIR PRESSURE	91
3.3.2	IDG 1(2) OIL OVHT	28	3.7.5	G(B)(Y) PUMP LO PR	93
3.3.3	IDG 1(2) OIL LO PR	31	3.7.6	B(Y) ELEC PUMP OVHT	95
3.3.4	AC BUS 1(2) FAULT	34	3.7.7	Y ELEC PUMP LO PR	96
3.3.5	AC ESS BUS FAULT	36	<b>3.8</b>	<b>DSC-31 INDICATING / RECORDING SYSTEMS</b>	<b>97</b>
3.3.6	STATIC INV FAULT	37	3.8.1	DMC 1(2)(3) FAULT	97
3.3.7	DC BUS 1(2) FAULT	38	3.8.2	SDAC 1(2) FAULT	98
3.3.8	DC BAT BUS FAULT	40	3.8.3	FWC 1(2) FAULT	99
3.3.9	DC ESS BUS FAULT	41	3.8.4	INDIVIDUAL DISPLAY FAULTS	100
3.3.10	TR 1(2) FAULT	43	<b>3.9</b>	<b>DSC-32 LANDING GEAR</b>	<b>101</b>
3.3.11	TRIPPABLE CIRCUIT BREAKERS	44	3.9.1	GEAR NOT DOWNLOCKED	101
<b>3.4</b>	<b>DSC-26 FIRE PROTECTION</b>	<b>52</b>	3.9.2	GEAR UPLOCK FAULT	102
3.4.1	AVIONICS SMOKE	52	3.9.3	GEAR NOT UNLOCKED	103
3.4.2	LAVATORY SMOKE	53	3.9.4	LGCIU 1(2) FAULT	104
3.4.3	LAVATORY SMOKE DET FAULT	54	3.9.5	NOSE WHEEL STEERING FAULT	106
3.4.4	CARGO SMOKE	55	3.9.6	A/BRK FAULT	107
3.4.5	CARGO SMOKE DET FAULT	56	3.9.7	LOSS OF BRAKING	108
3.4.6	CARGO SQUIB FAULT	57	3.9.8	BSCU 1+2 FAULT	109
<b>3.5</b>	<b>DSC-27 FLIGHT CONTROLS</b>	<b>58</b>	3.9.9	BRAKES HOT	110
3.5.1	L(R) SIDESTICK FAULT	58	<b>3.10</b>	<b>DSC-34-NAV NAVIGATION &amp; DSC-34-SURV SURVEILLANCE</b>	<b>111</b>
3.5.2	L(R) SIDESTICK PITCH(ROLL) STUCK	59	3.10.1	IR 1(2)(3) FAULT	111
3.5.3	L(R) SIDESTICK PITCH(ROLL) REVERSAL	60	3.10.2	IR 1(2)(3) FAULT (ATT AVAIL)	113
3.5.4	RUDDER PEDALS JAMMED	61	3.10.3	ADR 1(2)(3) FAULT	115
			3.10.4	CAPT(F/O)(STBY) PITOT BLOCKED	117
			3.10.5	CAPT(F/O)(STBY) STATIC BLOCKED	119

3.10.6	GPS PRIMARY LOST.....	121
3.10.7	RNP NAV ACCURACY DOWNGRAD .....	122
3.10.8	ILS 1(2) RCVR FAULT.....	123
3.10.9	UNSERVICEABLE NAVAIDS .....	124
3.10.10	GROUND LOC XMTR FAULT .....	125
3.10.11	GROUND G/S XMTR FAULT .....	126
3.10.12	RA 1(2) FAULT.....	127
3.10.13	GPWS FAULT .....	128
3.10.14	GPWS TERR DET FAULT .....	129
3.10.15	GLASS MOUNTAIN.....	130
3.10.16	TCAS EVENT GENERATOR.....	131
3.10.17	RUNWAY THR(MID) INCURSION .....	133

**3.11 DSC-49 APU 134**

---

3.11.1	APU FAULT .....	134
3.11.2	APU FIRE.....	135
3.11.3	APU GEN FAULT .....	136
3.11.4	APU BLEED FAULT.....	137

**3.12 DSC-52 DOORS 138**

---

3.12.1	CABIN DOORS FAULT .....	138
--------	-------------------------	-----

3.12.2	EMER EXITS FAULT .....	139
3.12.3	SLIDES ARMING FAULT .....	140
3.12.4	CARGO DOORS FAULT .....	141
3.12.5	AVIONICS DOORS FAULT .....	142

**3.13 DSC-70 ENGINES 143**

---

3.13.1	ENG 1(2) FLAMEOUT .....	143
3.13.2	ENG 1(2) FAULT – NO RELIGHT .....	144
3.13.3	ENG 1(2) SEVERE DAMAGE .....	145
3.13.4	ENG 1(2) FIRE.....	146
3.13.5	ENG 1(2) FADEC HI TEMP.....	148
3.13.6	ENG 1(2) EPR MODE FAULT .....	149
3.13.7	ENG 1(2) OIL LO PR.....	150
3.13.8	ENG 1(2) OIL TEMP ADV.....	151
3.13.9	ENG 1(2) OIL HI TEMP .....	152
3.13.10	ENG 1(2) OIL LEAK.....	153
3.13.11	ENG 1(2) START FAULT – EGT OVERLIMIT .....	154
3.13.12	ENG 1(2) START FAULT – IGNITION FAULT .....	155
3.13.13	ENG 1(2) START FAULT – START VALVE FAULT .....	156
3.13.14	ENG 1(2) IGN A(B) FAULT .....	157
3.13.15	ENG 1(2) N1(2) VIBRATIONS .....	158